

ZoneGuard Quick Start Guide

Everything you need to get started with your flashing, dashing weather alert radio system. For even more details, consult the Owner's Manual.

1 SET IT UP

PLUG IT IN

Use the enclosed AC adapter. (For emergency backup, pop in three AA batteries.)

SET THE CLOCK

- Press <Menu>.
- Press <◀> or <▶>. When the hour flashes, press <▲> or <▼> to adjust.
- Press <◀> or <▶>. When the minute flashes, press <▲> or <▼> to adjust.
- Press <Menu> twice to confirm and exit.

2 STAY ALERT

FIND YOUR S.A.M.E. CODE

To receive S.A.M.E. (Specific Area Message Encoding) notifications for your area, you'll need to get your 6 digit code(s) at:

In the U.S. go to:

<http://www.nws.noaa.gov/nwr/indexnw.htm>

In Canada, go to:

<http://ec.gc.ca/meteo-weather/default.asp?lang=En&n=1CD5BDF2-1>

SELECT YOUR COUNTY

- ZoneGuard lets you choose which alerts to receive—SINGLE for one area; MULTIPLE for up to 25 areas; ALL for everywhere...or in case you don't know your code.
- With radio OFF, press <Menu>, then press <▲> or <▼> to select <COUNTY - ALL/SINGL/MULTI> mode.
- Press <◀> or <▶>, when mode flashes, press <▲> or <▼> to select.

ENTER YOUR CODE

- With selected mode still flashing, press <◀> or <▶> to begin.
- Press <◀> or <▶> to set first code digit. Press <▲> or <▼> to adjust. Repeat for all other digits.
- Press <Menu> twice to confirm and exit.

SET ALERT MODE

- Press <Menu>, then press <▲> or <▼> to select <ALERT - SIREN/ VOICE> mode.
- Press <◀> or <▶>, when the <SIREN/VOICE> flashes, press <▲> or <▼> to select.
- Press <Menu> twice to confirm and exit.

3 GET THE WEATHER

- Press <Ⓟ> to turn radio ON, then press <WB> (on left side).
- Press <▲> or <▼> to scroll through CH 1 - 7. The clearest is your local NOAA channel.
- For standby mode, press <WB/ALERT> (on left side) to receive alerts even when your radio is turned off.

4 TUNE IN TO RADIO

- Press <Ⓟ> to turn radio ON, then press <AM/FM> (on left side).
- Adjust volume with <+/-> (on right side).
- Tune stations with <▲> or <▼>, Manually tune with short press. Auto tune with two-second press.
- To store a station, press <MEMORY> (on left side and any of the buttons marked 1 - 6).